

when it has to be **right**



## UPDATE LEICA SOFTWARE AND FIRMWARE FOR RTC360

### Updating Leica Software

Login to your account: [Login | myWorld](#)

Scroll down and click on Access Downloads.

Scroll down and click on Laser Scanning Software.

Click on Cyclone.

Click on Software.

Click on Download next to Cyclone Register 360 Plus.

### Updating Leica RTC360 Firmware

Login to your account: [Login | myWorld](#)

Scroll down and click on Access Downloads.

Scroll down and click on Laser Scanning Software.

Click on RTC360 Laser Scanner.

Click on Software.

Click on Download next to RTC360 Firmware to download the newest firmware version.

Save the Zip file on the RTC thumb drive.

Plug the thumb drive into the RTC. On the touchscreen of the RTC, scroll down to firmware update, click, and then follow the instructions.



[atgusa.com](http://atgusa.com)

(800) 935-4894